

1. Product introduction


This is an innovative switch dedicated to controlling the suspension fan. The separation design between the panel and the module is connected through wireless connections. This installation is very convenient and can achieve mobile phones, voice, Google Home and Alexa, etc.

Please keep this manual for future reference.

2. Product parameters

Name: LCD Fan Smart Switch
Fan switch: 86mmx86mm/120mmx74mm
Panel: Tempered Crystal Glass
Amperage: 1A
Fan Power: Fan 200W, Light 200W
Rated voltage: AC110V-250V
Wireless standards: IEEE 802.11b/g/n
Wifi frequency: 2.4G
Wireless frequency: 433Mhz
Operating temperature: -10℃ +60℃
Relative humidity: <95%

3. Product wiring diagram




4. System structure diagram




5. Product size

EUR Standard




USA Standard



6. Product description

Fan Switch



- ① WiFi, "White" connected, "Red" not connected.
- ② Total number of devices in the mesh network
- ③ Current time
- ④ Power or the statistics of electricity consumption
- ⑤ Fan & Light Switch
- ⑥ Normal wind
- ⑦ Natural wind
- ⑧ Sleeping wind

7. Product installation diagram

1. Use the standard mounting box, the European version uses the mounting box shown in Figure 1, and the US version uses the Figure 2 mounting box.
2. Disconnect the power supply and wire according to the wiring diagram. Screwdriver: M5 Torque: 0.5N.m Wire range: 24-12AWG.
3. Put the switch into the installation box and tighten the screws to fix it.
4. Cover the panel, power on.

8. How to download the APP

Scan the QR code below with your mobile phone to download the Smart Life APP.



Scan the QR code below with your mobile phone to download the Tuya APP.



9. Configure to the Smart Life APP Way 1: Bluetooth-Mode

1. Power on the switch, select the type.
2. ON/OFF, Edge lighting.
3. Enter configuration state.
4. (Only supported by certain types) First turn on the phone's Bluetooth.
5. Open the Smart Life APP.
6. Click Add Device.
7. If the current device supports Bluetooth configuration, Smart Life APP will automatically discover new devices nearby that are not configured with a network and pop up an add window.
8. Enter the currently connected WiFi password, and then click 'Next'.
9. The device has been added.

10. Configure to the Smart Life APP Way 2: EZ-Mode

1. Long press for 3 seconds.
2. Open the Smart Life APP.
3. Click 'Add Device' or '+' to add a device.
4. "Electrical" Click "Switch (Wi-Fi)".
5. Select the router and enter the correct password.
6. Select "Blink Quickly" and then check "Confirm..." and click "Next".
7. Wait for the device to be added.
8. The device has been added.
9. The device has been added "Click OK".
10. Failed to add device, try again after confirming the reason.
11. WiFi Config Success! Please confirm the LAN host Network is connected.
12. WiFi Config Failed! Please confirm the LAN host Network is connected.
13. WiFi Config Network is connected.

11. Fan switch mode selection

1. Enter the main menu.
2. Select system Config.
3. Select mode settings.
4. Choose only the fan switch or choose a fan & light switch.

12. How to Change button name and icon


1. Long press for 3 seconds.
2. Click to change icon.
3. Click to change name.

13. How to set the wind speed of each gear?


1. Enter the main menu.
2. Select system Config.
3. Select gear scale.
4. The speed of the fan will be adjusted in real time according to your settings, please confirm that the wind speed is saving and exiting.

14. How to set up Green mode?


The Green mode is the maximum time we allow the device to work. In this case, when you forget to turn off the device, the system will automatically shut down.




15. How to adjust the Button Color to your favorite color?




16. How to do Timer setting?



17. How to adjust the Edge lighting to your favorite color?




18. How to turn ON /OFF the Edge Lighting ?




19. How to set up the state before power outage?


(This function is mainly used in areas where frequent power outage is stopped)




20. How do I upgrade ?




21. How to change the background image of the switch?



22. Factory reset to restore default settings



23. How to connect Alexa?



24. How to connect Google home?



25. Distributor



Wirplast - Więcek Spółka Jawna
42-287 Babienica, Stawowa 9A
VAT ID: 5751889123

www.wirplast.pl